



# NGRM700

## Neutral Grounding Resistor Monitor





**Bender GmbH & Co. KG**

Londorfer Str. 65 • 35305 Grünberg • Germany

PO Box 1161 • 35301 Grünberg • Germany

Tel.: +49 6401 807-0 • Fax: +49 6401 807-259

E-Mail: [info@bender.de](mailto:info@bender.de) • [www.bender.de](http://www.bender.de)

© Bender GmbH & Co. KG

All rights reserved.

Reprinting only with permission of the publisher.

Subject to change!

Photos: Bender archive.

# Table of Contents

<b>1. Important information .....</b>	<b>7</b>
1.1 How to use this manual .....	7
1.2 Technical support: service and support .....	8
1.2.1 First level support .....	8
1.2.2 Repair service .....	8
1.2.3 Field service .....	8
1.3 Training courses .....	9
1.4 Delivery conditions .....	9
1.5 Inspection, transport and storage .....	9
1.6 Warranty and liability .....	10
1.7 Disposal .....	10
<b>2. Safety instructions .....</b>	<b>11</b>
2.1 General safety instructions .....	11
2.2 Work activities on electrical installations .....	11
2.3 Intended use .....	11
2.4 Glossary .....	12
<b>3. Function .....</b>	<b>13</b>
3.1 Device features .....	13
3.2 Functional description .....	14
3.3 Recommended minimum value RNGR (tripping level 50 %) .....	15
3.3.1 Recommended RNGR for system voltage $U_{\text{sys}} \leq 4300 \text{ V}$ .....	15
3.3.2 Recommended RNGR for system voltage $U_{\text{sys}} > 4300 \text{ V}$ .....	16
<b>4. Installation .....</b>	<b>17</b>
4.1 Screw mounting .....	17
4.2 Dimension diagrams .....	17
4.2.1 Dimension diagram FP200-NGRM .....	17

4.2.2	Dimension diagram NGRM700 .....	18
4.3	Enclosure view .....	19
4.4	Removing FP200-NGRM from enclosure .....	19
4.5	Door mounting .....	20
4.6	Front cover for FP200-NGRM .....	20
<b>5.</b>	<b>Connection .....</b>	<b>21</b>
5.1	Connection requirements .....	21
5.2	Connection descriptions of CD-series coupling device .....	22
5.3	Star connection .....	23
5.3.1	Connection $U_{\text{sys}} \leq 690 \text{ V}$ .....	23
5.3.2	Connection $U_{\text{sys}} \leq 690 \text{ V}$ with pulser .....	24
5.3.3	Connection $U_{\text{sys}} > 690 \text{ V}$ .....	25
5.3.4	Artificial neutral (delta connection) .....	26
5.4	Measuring current transformer connection .....	27
5.5	Connection of relays (ground-fault, NGR and trip relay) .....	28
5.6	Connection to the X1 interface .....	28
5.6.1	X1: Input I1...3 .....	29
5.6.2	X1: Output Q1...2 .....	30
5.6.3	X1: Analogue output .....	31
<b>6.</b>	<b>User interface FP200-NGRM .....</b>	<b>32</b>
6.1	Standard display .....	34
6.2	Fault indication (active) .....	34
6.3	Fault indication (inactive) .....	35
6.4	Acknowledging a fault message .....	35
6.5	History memory .....	36
<b>7.</b>	<b>Menu .....</b>	<b>37</b>
7.1	Overview .....	37
7.2	Navigating through the menu .....	38
7.3	Changing settings .....	38
7.4	Data measured values (menu 1) .....	38
7.5	Harmonics (menu 2) .....	39

7.6	History (menu 3) .....	40
7.7	Pulser (menu 4) .....	40
7.8	Display (menu 5) .....	41
7.9	HRG settings (menu 6) .....	41
7.9.1	HRG system (menu 6.1) .....	41
7.9.2	CT (menu 6.2) .....	41
7.9.3	NGR (menu 6.3) .....	42
7.9.4	Phase monitor (menu 6.4) .....	42
7.9.5	Response values (menu 6.5) .....	42
7.9.6	System settings (menu 6.6) .....	46
7.9.7	Field calibration (menu 6.7) .....	47
7.10	Device settings (menu 7) .....	47
7.11	Commissioning (menu 8) .....	52
7.12	Info (menu 9) .....	52
7.13	Alarm (menu 10) .....	53
<b>8.</b>	<b>Initial commissioning .....</b>	<b>54</b>
8.1	Response values .....	54
8.2	Output relays operating modes .....	55
8.2.1	Field calibration .....	55
8.2.2	Trip times .....	55
8.3	RMS trip signal, fundamental, harmonics .....	58
8.4	Initial measurement .....	58
<b>9.</b>	<b>Analogue and digital I/O configuration .....</b>	<b>60</b>
9.1	Analogue output (menu 6.6.4) .....	60
9.2	Digital outputs (Q1, Q2) .....	60
9.2.1	Use of Q1: Device condition .....	61
9.2.2	Use of Q2: Pulser .....	61
9.3	Digital input .....	61
<b>10.</b>	<b>Test cycle .....</b>	<b>62</b>
<b>11.</b>	<b>Factory settings .....</b>	<b>63</b>

<b>12. Error codes .....</b>	<b>65</b>
<b>13. Technical data .....</b>	<b>66</b>
13.1 Tabular data .....	66
13.2 Ordering details .....	72
13.2.1 NGR monitor .....	72
13.2.2 Accessories .....	72
13.3 Document revision history .....	73

# 1. Important information

## 1.1 How to use this manual



This manual is intended for **qualified personnel** working in electrical engineering and electronics!

**Always keep this manual within easy reach for future reference.** To make it easier for you to understand and revisit certain sections in this manual, we have used symbols to identify important instructions and information. The meaning of these symbols is explained below:



**DANGER**

This signal word indicates that there is a **high risk of danger** that will result in **electrocution** or **serious injury** if not avoided.



**WARNING**

This signal word indicates a **medium risk of danger** that can lead to **death** or **serious injury** if not avoided.



**CAUTION**

This signal word indicates a **low-level risk** that can result in **minor or moderate injury** or **damage to property** if not avoided.



This symbol denotes information intended to assist the user in making **optimum use** of the product.

This manual has been compiled with great care. It might nevertheless contain errors and mistakes. Bender cannot accept any liability for injury to persons or damage to property resulting from errors or mistakes in this manual.

## 1.2 Technical support: service and support

For commissioning and troubleshooting Bender offers you:

### 1.2.1 First level support

Technical support by phone or e-mail for all Bender products

- Questions concerning specific customer applications
- Commissioning
- Troubleshooting

**Telephone:** +49 6401 807-760\*  
**Fax:** +49 6401 807-259  
In Germany only: 0700BenderHelp (Tel. and Fax)  
**E-mail:** support@bender-service.de

### 1.2.2 Repair service

Repair, calibration, update and replacement service for Bender products

- Repairing, calibrating, testing and analysing Bender products
- Hardware and software update for Bender devices
- Delivery of replacement devices in the event of faulty or incorrectly delivered Bender devices
- Extended guarantee for Bender devices, which includes an in-house repair service or replacement devices at no extra cost

**Telephone:** +49 6401 807-780\*\* (technical issues)  
+49 6401 807-784\*\*, -785\*\* (sales)  
**Fax:** +49 6401 807-789  
**E-mail:** repair@bender-service.de

Please send the devices for **repair** to the following address:

Bender GmbH, Repair-Service,  
Londorfer Straße 65,  
35305 Grünberg

### 1.2.3 Field service

On-site service for all Bender products

- Commissioning, parameter setting, maintenance, troubleshooting for Bender products
- Analysis of the electrical installation in the building (power quality test, EMC test, thermography)
- Training courses for customers



**Telephone:** +49 6401 807-752\*\*, -762 \*\*(technical issues)  
+49 6401 807-753\*\* (sales)  
**Fax:** +49 6401 807-759  
**E-mail:** fieldservice@bender-service.de  
**Internet:** www.bender-de.com

\*Available from 7.00 a.m. to 8.00 p.m. 365 days a year (CET/UTC+1)

\*\*Mo-Thu 7.00 a.m. - 8.00 p.m., Fr 7.00 a.m. - 13.00 p.m.

### 1.3 Training courses

Bender is happy to provide training regarding the use of test equipment. The dates of training courses and workshops can be found on the Internet at [www.bender.de](http://www.bender.de) > Know-how > Seminars.

### 1.4 Delivery conditions

Bender sale and delivery conditions apply.

For software products the "Softwareklausel zur Überlassung von Standard-Software als Teil von Lieferungen, Ergänzung und Änderung der Allgemeinen Lieferbedingungen für Erzeugnisse und Leistungen der Elektroindustrie" (software clause in respect of the licensing of standard software as part of deliveries, modifications and changes to general delivery conditions for products and services in the electrical industry) set out by the ZVEI (Zentralverband Elektrotechnik- und Elektronikindustrie e. V.) (German Electrical and Electronic Manufacturer's Association) also applies.

Sale and delivery conditions can be obtained from Bender in printed or electronic format.

### 1.5 Inspection, transport and storage

Inspect the dispatch and equipment packaging for damage, and compare the contents of the package with the delivery documents. In the event of damage in transit, please contact Bender immediately.

The devices must only be stored in areas where they are protected from dust, damp, and spray and dripping water, and in which the specified storage temperatures can be ensured.

## 1.6 Warranty and liability

Warranty and liability claims in the event of injury to persons or damage to property are excluded if they can be attributed to one or more of the following causes:

- Improper use of the device.
- Incorrect mounting, commissioning, operation and maintenance of the device.
- Failure to observe the instructions in this operating manual regarding transport, commissioning, operation and maintenance of the device.
- Unauthorised changes to the device made by parties other than the manufacturer.
- Non-observance of technical data.
- Repairs carried out incorrectly and the use of replacement parts or accessories not approved by the manufacturer.
- Catastrophes caused by external influences and force majeure.
- Mounting and installation with device combinations not recommended by the manufacturer.

This operating manual, especially the safety instructions, must be observed by all personnel working on the device. Furthermore, the rules and regulations that apply for accident prevention at the place of use must be observed.

## 1.7 Disposal

Abide by the national regulations and laws governing the disposal of this device. Ask your supplier if you are not sure how to dispose of the old equipment.

The directive on waste electrical and electronic equipment (WEEE directive) and the directive on the restriction of certain hazardous substances in electrical and electronic equipment (RoHS directive) apply in the European Community. In Germany, these policies are implemented through the "Electrical and Electronic Equipment Act" (ElektroG). According to this, the following applies:

- Electrical and electronic equipment are not part of household waste.
- Batteries and accumulators are not part of household waste and must be disposed of in accordance with the regulations.
- Old electrical and electronic equipment from users other than private households which was introduced to the market after 13 August 2005 must be taken back by the manufacturer and disposed of properly.

For more information on the disposal of Bender devices, refer to our homepage at [www.bender.de](http://www.bender.de) > Service & support.

## 2. Safety instructions

### 2.1 General safety instructions

Part of the device documentation in addition to this manual is the enclosed " Safety instructions for Bender products".

### 2.2 Work activities on electrical installations



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



**DANGER**

#### ***Danger of electrocution due to electric shock!***

*Touching live parts of the system carries the risk of:*

- An electric shock
- Damage to the electrical installation
- Destruction of the device

***Before installing and connecting the device, make sure that the installation has been de-energised. Observe the rules for working on electrical installations.***

If the device is used outside the Federal Republic of Germany, the applicable local standards and regulations must be complied with. The European standard EN 50110 can be used as a guide.

### 2.3 Intended use

The NGRM700 is only intended for use in high-resistance grounded systems. In these systems, the NGRM700 monitors

- the current through the neutral-grounding resistor (NGR),
- the voltage between the star point of the transformer and earth (voltage drop across the NGR),
- the condition of the NGR,
- line-to-line and line-to-earth voltages.



*Systems with a high-resistance grounded star point can be used when an **interruption of the power supply would involve excessive costs due to production stoppage** (e.g. automotive production, chemical industry). The ground fault that occurs between a phase and earth does not lead to a failure of the power supply in these systems. A ground fault must be detected and eliminated as quickly as possible, since the occurrence of another ground fault in a second phase would lead to a tripping of the overcurrent protective device.*

In order to meet the requirements of applicable standards, the equipment must be adjusted to local equipment and operating conditions by means of customised parameter settings. Please heed the limits of the range of application indicated in the technical data.

Any other use than that described in this manual is regarded as improper. Intended use includes following all the instructions in this operating manual.

## 2.4 Glossary

<b>CD</b>	<b>C</b> oupling <b>D</b> evice CD-series
<b>CT</b>	<b>C</b> urrent <b>T</b> ransformer
<b>FFT</b>	<b>F</b> ast <b>F</b> ourier <b>T</b> ransformation
<b>HMI</b>	<b>H</b> uman <b>M</b> achine <b>I</b> nterface, display unit
<b>HRG</b>	<b>H</b> igh <b>R</b> esistance <b>G</b> rounding
$I_{\text{NGR}}$	NGR rated current
$I_{\text{NGR nom}}$	Nominal current through the NGR
<b>NER</b>	<b>N</b> eutral <b>E</b> arthing <b>R</b> esistor (NER = NGR)
<b>NGR</b>	<b>N</b> eutral <b>G</b> rounding <b>R</b> esistor
<b>NTP</b>	<b>N</b> etwork <b>T</b> ime <b>P</b> rotocol
<b>PT</b>	<b>P</b> otential <b>T</b> ransformer
$R_{\text{NGR}}$	NGR resistance value
$R_{\text{NGR nom}}$	NGR nominal resistance
$R_{\text{S}}$	Sense resistor; CD-series coupling device
<b>PLC</b>	<b>P</b> rogrammable <b>L</b> ogic <b>C</b> ontroller
$U_{\text{NGR}}$	Voltage on the NGR
$U_{\text{NGR nom}}$	Nominal voltage across the NGR
$U_{\text{sys}}$	System voltage
<b>UTC</b>	<b>U</b> niversal <b>T</b> ime <b>C</b> oordinated

## 3. Function

### 3.1 Device features

- Determination of  $R_{\text{NGR}}$  with passive and active measurement methods
- Continuous monitoring of the  $R_{\text{NGR}}$  even if the installation is de-energised;
- Alarm or trip on ground fault
- Monitoring of the current  $I_{\text{NGR}}$
- Monitoring of the voltage  $U_{\text{NGR}}$
- Phase-to-ground fault indication (optional; up to 690 V direct coupling, otherwise via potential transformers)
- Ethernet communication
- Web server
- Language selection (German, English GB and US, Spanish, French)
- Test button (internal, external) with/without tripping
- FFT analysis of the measuring signals
- Pulser for manual ground fault location
- Relay for detection of ground faults and resistor faults
- Relay for shutdown of the installation after a configurable time
- Can be combined with RCMS... for automatic shutdown of feeders
- Graphical user interface
- Wide supply voltage range (24 to 240 Vac/Vdc)
- Range of use up to 5000 m AMSL
- Fault/History memory
- Analogue output of measured values (0...10 V, 4...20 mA, selectable parameters)
- Detachable HMI for door mounting
- Password protection
- Tripping on RMS, fundamental component signal or harmonics
- Detection of AC and DC ground faults

### 3.2 Functional description

The NGRM700 monitors NGR resistance  $R_{\text{NGR}}$ , neutral voltage  $U_{\text{NGR}}$  and current  $I_{\text{NGR}}$ . NGR resistance is monitored using an active and a passive procedure:

active	The device generates an active test pulse and measures $R_{\text{NGR}}$ even if the installation is de-energised.
passive	Only for energised installations: The resistance $R_{\text{NGR}}$ is determined when $I_{\text{NGR}}$ or $U_{\text{NGR}}$ exceeds an internal threshold. The device measures the existing current and voltage and calculates $R_{\text{NGR}}$ .

In the case of the "auto" method, monitoring switches automatically between "active" and "passive" when the measured value exceeds or falls below the internal threshold. The threshold is 15 % of the nominal value and can be adjusted by Bender service if required.

A short circuit or interruption of the NGR is reliably detected in an energised as well as a de-energised installation with the active measurement method.

When the "passive" method is selected, no switching of the monitoring takes place. No monitoring of the NGR occurs while the installation is de-energised.

The NGR relay switches from alarm state to operating state when the measured resistance  $R_{\text{NGR}}$  is within the configured thresholds.

A ground fault is signalled via the corresponding ground-fault relay when  $I_{\text{NGR}}$  or  $U_{\text{NGR}}$  exceeds the selectable thresholds. After the adjustable time delay has elapsed, the installation can be shut down by means of the trip relay.

A connection to installations ranging from 400 V...25 kV is possible via the appropriate CD-series coupling device.

The  $I_{\text{NGR}}$  is measured with (universal) **measuring current transformers** for 5 A or 50 mA secondary. With the ratio of the used measuring current transformer the current measurement is internally set in such a way that it adjusts best to  $I_{\text{NGR}}$ .

The **phase-voltage monitoring** function can be used to indicate which phase has the ground fault. Direct coupling is possible up to a system voltage of 690 V. For higher voltages, use potential transformers (PT). The ratio is adjustable.

### 3.3 Recommended minimum value $R_{NGR}$ (tripping level 50 %)

Temperature range  $-40\dots+70\text{ °C}$ , field calibration at  $25\text{ °C}$

(Limited temperature range  $0\dots+40\text{ °C}$ , field calibration at  $25\text{ °C}$ )

#### 3.3.1 Recommended $R_{NGR}$ for system voltage $U_{sys} \leq 4300\text{ V}$

$U_{sys}$	CD1000/CD1000-2			CD1000-2	CD5000	
	400 V	600 V	690 V	1000 V	2400 V	4200 V
$I_{NGR}$						
1 A	231 $\Omega$	346 $\Omega$	398 $\Omega$	577 $\Omega$	1386 $\Omega$	—
5 A	46 $\Omega$	69 $\Omega$	80 $\Omega$	115 $\Omega$	277 $\Omega$	485 $\Omega$
10 A	(23 $\Omega$ )	35 $\Omega$	40 $\Omega$	58 $\Omega$	139 $\Omega$	242 $\Omega$
15 A	(15 $\Omega$ )	(23 $\Omega$ )	(27 $\Omega$ )	38 $\Omega$	92 $\Omega$	162 $\Omega$
20 A	—	(17 $\Omega$ )	(20 $\Omega$ )	29 $\Omega$	69 $\Omega$	121 $\Omega$
25 A	—	—	(16 $\Omega$ )	(23 $\Omega$ )	55 $\Omega$	97 $\Omega$
30 A	—	—	—	(19 $\Omega$ )	(46 $\Omega$ )	81 $\Omega$
40 A	—	—	—	—	(35 $\Omega$ )	61 $\Omega$
50 A	—	—	—	—	(28 $\Omega$ )	(48 $\Omega$ )
100 A	—	—	—	—	—	(24 $\Omega$ )

Tab. 3.1: Recommended  $R_{NGR}$  for system voltage  $U_{sys} \leq 4300\text{ V}$

### 3.3.2 Recommended $R_{NGR}$ for system voltage $U_{sys} > 4300$ V

	CD14400					CD25000
$U_{sys}$	6000 V	6600 V	7200 V	11000 V	14400 V	25000 V
$I_{NGR}$						
1 A	—	—	—	—	—	—
5 A	693 $\Omega$	762 $\Omega$	831 $\Omega$	1270 $\Omega$	1663 $\Omega$	—
10 A	346 $\Omega$	381 $\Omega$	416 $\Omega$	635 $\Omega$	831 $\Omega$	1443 $\Omega$
15 A	231 $\Omega$	254 $\Omega$	277 $\Omega$	423 $\Omega$	554 $\Omega$	962 $\Omega$
20 A	(173 $\Omega$ )	191 $\Omega$	208 $\Omega$	318 $\Omega$	416 $\Omega$	722 $\Omega$
25 A	(139 $\Omega$ )	(152 $\Omega$ )	(166 $\Omega$ )	254 $\Omega$	333 $\Omega$	577 $\Omega$
30 A	(115 $\Omega$ )	(127 $\Omega$ )	(139 $\Omega$ )	212 $\Omega$	277 $\Omega$	481 $\Omega$
40 A	(87 $\Omega$ )	(95 $\Omega$ )	(104 $\Omega$ )	(159 $\Omega$ )	208 $\Omega$	361 $\Omega$
50 A	—	(76 $\Omega$ )	(83 $\Omega$ )	(127 $\Omega$ )	(166 $\Omega$ )	289 $\Omega$
100 A	—	—	—	—	(83 $\Omega$ )	(144 $\Omega$ )

Tab. 3.2: Recommended  $R_{NGR}$  for system voltage  $U_{sys} > 4300$  V



## 4. Installation



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



*Danger of electrocution due to electric shock!  
Touching live parts of the system carries the risk of:*

- An electric shock
- Damage to the electrical installation
- Destruction of the device


**Before installing and connecting the device, make sure that the installation has been *de-energised*.** Observe the rules for working on electrical installations.

### 4.1 Screw mounting

Fix the NGRM700 with four M4 screws (see dimension diagram NGRM700).

### 4.2 Dimension diagrams


#### 4.2.1 Dimension diagram FP200-NGRM



	mm	in
<b>a</b>	135.5	5.33
<b>b</b>	65.5	2.58
<b>c</b>	35.6	1.40
<b>d</b>	144	5.67
<b>e</b>	72	2.83
<b>f</b>	5.8	0.23

Fig. 4.1: Dimension diagram FP200-NGRM

**4.2.2 Dimension diagram NGRM700**



*Fig. 4.2: Dimension diagram and mounting position NGRM700*

### 4.3 Enclosure view




Fig. 4.3: Enclosure view

### 4.4 Removing FP200-NGRM from enclosure




Fig. 4.4: Removing FP200-NGRM from enclosure

## 4.5 Door mounting





Fig. 4.5: Door mounting

## 4.6 Front cover for FP200-NGRM

When installed in doors, the degree of protection of the FP200-NGRM operator unit can be increased to IP65 by means of the transparent front plate cover (B98060005).

Place the front cover over the yellow front of the FP200-NGRM **before installing it**.



# 5. Connection

## 5.1 Connection requirements



Only **qualified personnel** are permitted to carry out the work necessary to install, commission and run a device or system.



**Danger of electrocution due to electric shock!**

Touching live parts of the system carries the risk of:

- An electric shock
- Damage to the electrical installation
- Destruction of the device

**Before installing and connecting the device, make sure** that the **installation** has been **de-energised**. Observe the rules for working on electrical installations.



**Danger of electrocution due to electric shock!**

**A nominal voltage of up to 690 V** may be present at the terminals L1...L3. Direct contact with these will likely result in **electrocution**.



**Provide line protection!**

According to IEC 60364-4-43, a line protection shall be provided for the supply voltage.



**Risk of property damage due to unprofessional installation!**

The connecting lines L1, L2, L3 to the system to be monitored must be carried out as spur lines. Inadmissible load current can result in damage to property and personal injury.

**Do not apply any load current to the terminals.**



**Check proper connection.**


Prior to commissioning of the installation, check that the device has been properly connected and check that the device functions.



**For UL applications:**

- Use 60/70 °C copper lines only.
- For UL and CSA applications, the supply voltage must be protected via **5 A** fuses.

## 5.2 Connection descriptions of CD-series coupling device



### 5.3 Star connection

#### 5.3.1 Connection $U_{sys} \leq 690\text{ V}$

For these voltages, the phase monitor of the NGRM700 can be connected directly to the conductors to be monitored.




Fig. 5.1: Star configuration (up to 690 V)



The "N" connection of the CD-series coupling device should be as close to the transformer star point as possible.

**5.3.2 Connection  $U_{sys} \leq 690$  V with pulser**




Fig. 5.2: Connection  $U_{sys} \leq 690$  V with pulser



The "N" connection of the CD-series coupling device should be as close to the transformer star point as possible.



An intermediate relay may be required between the power contactor of the pulser and the digital output at X1 of the FP200-NGRM.



### 5.3.3 Connection $U_{sys} > 690\text{ V}$

For these voltages, the phase monitor of the NGRM700 can only be connected to the conductors to be monitored via potential transformers (PT).




Fig. 5.3: Star configuration ( $U_{sys} > 690\text{ V}$ )

Note:

\* PT ratio "primary: secondary" can be adjusted in the NGRM700



The "N" connection of the CD-series coupling device should be as close to the transformer star point as possible.

### 5.3.4 Artificial neutral (delta connection)

If no star point is available, the following circuit can create an artificial neutral.

#### Connection with a zigzag transformer

Circuit breaker (for tripping systems)










Fig. 5.4: Artificial neutral with a zigzag transformer

### 5.4 Measuring current transformer connection

Depending on the system to be monitored, a suitable measuring current transformer has to be chosen. All common measuring current transformers (50 mA or 5 A on the secondary side) can be used. The following table helps you with the choice:

System type	AC + DC	AC	AC
$I_{NGR}$	1...25A	5...25 A	5...100 A
$f$	0...3800 Hz	42...3800 Hz	50/60 Hz
Bender CT ratio	600:1	600:1	60:5
Length connecting cables	max. 30 m	max. 40 m	max. 25 m (4 mm <sup>2</sup> /AWG 12) max. 40 m (6 mm <sup>2</sup> /AWG12)
	provided cable or cable of 0.75...1.5 mm <sup>2</sup> /AWG18...16		
$I_{\Delta n}$ (Currents detected)	 AC, pulsed AC, DC	 AC, pulsed A	 AC, pulsed A
Type	CTUB103 	W20...120 W1-S35...W5-S210 	CTB31...41 
CT: Terminal k	NGRM700: <b>50 mA</b>	NGRM700: <b>50 mA</b>	NGRM700: <b>5 A</b>
CT: Terminal l	NGRM700: <b>C</b>	NGRM700: <b>C</b>	NGRM700: <b>C</b>

Tab. 5.1: Selecting the right measuring current transformer

## 5.5 Connection of relays (ground-fault, NGR and trip relay)





Fig. 5.5: Connection of relays


## 5.6 Connection to the X1 interface

	I1	Pulser IN
	I2	Reset IN
	I3	Test IN
	A	Modbus RTU (A)
	B	Modbus RTU (B)
	⊥	Ground
	M+	Analogue output
	Q2	Open Collector: Pulser OUT
	Q1	Open Collector: Device condition (device health)
	+	Output for supply of external relays (+24 V, max. 100 mA)

Tab. 5.2: Pin assignment X1 interface

### 5.6.1 X1: Input I1...3

The input is only detected as "activated" after the contact has been activated for at least 150 ms. This way, short interference pulses are ignored.




Input I1...3:

Potential-free contact to ground or  
0 V and 24 V in conjunction with a PLC


## 5.6.2 X1: Output Q1...2

### Internal 24 V




FP200-NGRM X1

### Connection to PLC



FP200-NGRM X1

### External supply e.g.12...24 V



FP200-NGRM X1

Connection to Q1, Q2: external relay or PLC



*Observe maximum current values!*

*The maximum **output current** on X1(+24 V) is **100 mA**.*

*In case of higher currents, the relays require an external 24-V supply.*

*The maximum current on **Q1 and Q2** is **300 mA** each.*

### 5.6.3 X1: Analogue output

Analogue output	Mode	Permissible load
Current output 	0...20 mA	$\leq 600 \Omega$
	4...20 mA	$\leq 600 \Omega$
	0...400 $\mu$ A	$\leq 4 \text{ k}\Omega$
Voltage output 	0... 10 V	$\geq 1 \text{ k}\Omega$
	2... 10 V	$\geq 1 \text{ k}\Omega$

Either NGR **current**  $I_{NGR}$  or NGR **resistance**  $R_{NGR}$  can be assigned to the analogue output. A voltage or current signal proportional to the measured value is applied to the output.

The following overview shows how the output signals (A or V) are proportional to the measured values ( $\Omega$  or A):





Fig. 5.6: Assignment of measured value to output signal



In "4...20 mA" and "2...10 V" mode an output signal of 0 mA or 0 V indicates a **wiring error of the analogue interface**.

## 6. User interface FP200-NGRM



Legend, FP200-NGRM


No.	Designation	Description
<b>Display elements</b>		
1	ON	Operation LED, green; on when power supply is available
2		The LC display shows device and measurement information.
3	SERVICE	The LED is on when there is either a device fault or a connection fault, and when the device is in maintenance mode.
4	TRIPPED	The LED is on when the trip relay has been tripped due to an NGR fault, a ground fault or a device error.
5	NGR FAULT	The LED flashes in case of a prewarning: NGR fault detected, NGR relay has tripped, trip relay has not tripped yet ( $t_{NGR\ trip}$ elapses). The LED is on when an NGR fault has been detected. Trip relay and NGR relay have tripped.
6	GROUND FAULT	The LED flashes in case of a prewarning: ground fault detected, ground-fault relay has tripped, trip relay has not tripped yet ( $t_{GF\ trip}$ elapses). The LED is on: ground fault detected, trip relay has tripped, installation has not been shut down yet.



No.	Designation	Description
<b>Device buttons</b>		
7	^	Navigates up in a list or increases a value.
8	MENU	Opens the device menu.
	ESC	Cancels the current process or navigates one step back in the device menu.
9	RESET	Resets alarms.
	<	Navigates backwards (e.g. to the previous setting step) or selects parameter.
10	TEST	Starts the device self test.
	>	Navigates forwards (e.g. to the next setting step) or selects parameter.
11	INFO	Shows information.
	v	Navigates down in a list or reduces a value.
12	DATA	Indicates data and values.
	OK	Confirms an action or a selection.
13	X1	Interface X1 (see page 28 for more details)
14	ETH	Ethernet interface
15	R on/off	Terminating resistor for A/B (Modbus RTU)
<b>Buzzer</b>		Active in case of alarm and/or test
<b>Rear side</b>		
	REMOTE	RJ45 port for connection of FP200-NGRM to enclosure
	X3	Without function

Tab. 6.1: Legend, FP200-NGRM

## 6.1 Standard display




The pulse symbol in the lower part of the display indicates that the resistance of the  $R_{NGR}$  is actively measured.




Return from any (sub)menu to the **standard display** by pressing and holding ESC for more than 2 s.


## 6.2 Fault indication (active)



An active fault is indicated on the display with a . While the upper part of the display turns orange and indicates the fault message. Depending on the fault type, the GROUND FAULT, NGR FAULT, TRIPPED or SERVICE LEDs will be on. If several fault messages appear, navigate through the faults using the  $\nabla$  and  $\wedge$  buttons.

### 6.3 Fault indication (inactive)



An inactive fault is indicated on the display with a . If more than one fault has occurred, the number of faults is also indicated in the lower part of the display. This message means that there has been a fault in the past but the device is no longer in fault condition. If several fault messages appear, navigate through the faults using the  $\downarrow$  and  $\uparrow$  buttons. In addition to the type of fault and the associated alarm value, you can see when the fault occurred and for how long it was active.

### 6.4 Acknowledging a fault message

In order to return to the standard display of the NGR monitor, the fault message must be acknowledged by means of the RESET button. Fault messages can only be reset when the cause of fault has been eliminated.

#### Acknowledging:

Press the RESET button, select "Acknowledge" and then OK to mute the buzzer and delete the messages from the standard display. After this, the NGR monitor returns to the standard display. No restart attempt takes place. The fault messages remain stored in the history memory.

#### Reset:

Press the RESET button, select "Reset" and then OK. The buzzer is muted and the fault messages are deleted from the standard display. If the installation is de-energised, restart attempts will be carried out, which will only be successful after the fault has been eliminated. The device returns to the standard display. The faults remain stored in the history.




*A **reset** can also be carried out via the input **I2**. It must be active for more than 150 ms.*

## 6.5 History memory

Up to 1023 alarm messages and device errors with date and time stamp can be stored in the history memory. If the maximum number of memory entries has been reached, the oldest entry will be overwritten by a new event record.

Display the history memory at MENU > 3. History



*Legend, display history memory*

No.	Description
1	View next message
2	Exit view
3	Fault description Alarm value
4	↳ Fault appeared (fault start time) → Fault disappeared (fault end time)
5	View previous message
6	Number of the selected fault/Fault message count


# 7. Menu

## 7.1 Overview

**1. Data meas. values**

$R_{NGR}$ ,  $R_{NGR}$  rel, Method,  $R_{sense}$ ,  $I_{rms}$ ,  $I_{rms}$  rel,  $U_{rms}$ ,  $U_{rms}$  rel,  $I_{fund}$ ,  $I_{fund}$  rel,  $U_{fund}$ ,  $U_{fund}$  rel,  $I_{harm}$ ,  $I_{harm}$  rel,  $U_{harm}$ ,  $U_{harm}$  rel,  $U_{L1L2}$ ,  $U_{L2L3}$ ,  $U_{L3L1}$ ,  $f$ ,  $U_{1-E rms}$ ,  $U_{2-E rms}$ ,  $U_{3-E rms}$ , T

**2. Harmonics**



**3. History**

History, Delete

**4. Pulser**

Pulser,  $t_{impuls}$

**5. Display**

$R_{NGR}$ ,  $I_{NGR}$

**6. HRG settings**

HRG system	$U_{sys}$ (L-L), $f$ , $I_{NGR nom}$ , $R_{NGR nom}$
CT	CT primary, CT secondary, CT connection
NGR	Method, PT primary, PT secondary
Phase monitor	Phase monitor, PT primary, PT secondary
Response values	$U_{NGR Trip}$ , $I_{NGR Trip}$ , $>R_{NGR}$ , $<R_{NGR}$ , $I_{NGR trip}$ , GF trip, $t_{GF trip}$ , Alarm stored, $t_{restart}$ , Max. no. of restarts, Trip signal, Upper limit harmonics, Lower limit harmonics
System settings	Earth fault relay ..... Mode, Relay test NGR relay ..... Mode, Relay test Trip relay ..... Mode, Relay test Analogue ..... Mode, Function Digital in/out ..... Device OUT, Pulser OUT, Pulser IN, Reset IN, Test IN Buzzer ..... Buzzer alarm, Buzzer test
Field calibration	

**7. Device settings**

Language, Clock, Interface, Display, Password, Factory setting, Software, Service

**8. Commissioning**

Setting Language, Clock,  $U_{sys}$  L-L,  $f$ ,  $I_{NGR nom}$ ,  $R_{NGR nom}$ , CT<sub>primary</sub>, CT<sub>secondary</sub>, CT<sub>Connection</sub>, Field calibration

**9. Info**

Device information, Software information, Clock and date information, Ethernet information

**10. Alarm**

Acknowledge, Reset, Test

## 7.2 Navigating through the menu

Select a submenu using the  $\downarrow$  and  $\uparrow$  buttons and press OK.


Return from any submenu to the main menu by pressing ESC or  $\leftarrow$ .



Return from any (sub)menu to the **standard display** by pressing and holding ESC for more than 2 s.

## 7.3 Changing settings

Enter settings with text/numbers directly on the FP200-NGRM. There is a corresponding presentation in the menu items:



$\downarrow$  and  $\uparrow$  buttons:

Scroll to the letter/number.

$\leftarrow$  and  $\rightarrow$  buttons:

Shift left and right in the word.

ESC:

Reject entry

OK:

Save entry

## 7.4 Data measured values (menu 1)

List of measured values. Navigate through the list using the  $\downarrow$  and  $\uparrow$  buttons.

Parameter	Description
$R_{NGR}$	NGR resistance value
$R_{NGR\ rel}$	NGR relative <sup>1)</sup> resistance value
Method	Measurement method (see menu 6.3)
$R_{Sense}$	Resistance value CD-series coupling device
$I_{RMS}$	Current RMS value
$I_{RMS\ rel}$	Current relative <sup>1)</sup> RMS value
$U_{RMS}$	Neutral voltage RMS value
$U_{RMS\ rel}$	Neutral voltage relative <sup>1)</sup> RMS value

Parameter	Description
$I_{fund}$	Current RMS value (fundamental frequency)
$I_{fund\ rel}$	Current relative <sup>1)</sup> RMS value (fundamental frequency)
$U_{fund}$	Neutral voltage RMS value (fundamental frequency)
$U_{fund\ rel}$	Neutral voltage relative <sup>1)</sup> RMS value (fundamental frequency)
$I_{harm}$	Current RMS value (for selected harmonic frequency range) <sup>2)</sup>
$I_{harm\ rel}$	Current relative <sup>1)</sup> RMS value (for selected harmonic frequency range) <sup>2)</sup>
$U_{harm}$	Neutral voltage RMS value (for selected harmonic frequency range) <sup>2)</sup>
$U_{harm\ rel}$	Neutral voltage relative <sup>1)</sup> RMS value (for selected harmonic frequency range) <sup>2)</sup>
$U_{L1L2}$	Line-to-line voltage RMS value
$U_{L2L3}$	
$U_{L3L1}$	
Frequency	System frequency
$U_{L1E}$	Line-to-earth voltage RMS value
$U_{L2E}$	
$U_{L3E}$	
Temperature	in the NGRM700

*Tab. 7.1: Data measured values (menu 1)*

#### Note

- 1) Relative measured values always indicate the ratio of the measured value to the nominal value.
- 2) The selected harmonics are configured in the menu 6.5.11 and 6.5.12.

## 7.5 Harmonics (menu 2)

The measured harmonics are represented in a bar graph as a percentage of the measured value in relation to the nominal value. Change between the harmonic **voltage** and **current** displays using the  $\vee$  and  $\wedge$  buttons.

Scroll through the **harmonics up to the 64<sup>th</sup> order** using the  $<$  and  $>$  buttons. Use ESC to return to the main menu.

## 7.6 History (menu 3)

Alarm messages (since switching on the device or deleting the last history) are saved.

**History:** Navigate through the list using the  $\vee$  and  $\wedge$  buttons.

**Delete:** After confirming, the history is irreversibly deleted.

## 7.7 Pulsar (menu 4)

A ground fault can be located by means of a measuring clamp and the pulser function. The pulser relay is designed as Open Collector.

### Pulsar (menu 4.1)

- **Active** - The pulser is continuously active regardless of ground faults that have occurred.
- **External** - The external input "Pulsar In" can activate the pulser at any time.
- **Auto** - The pulser activates automatically in the event of a ground fault.
- **Inactive** - The pulser output is disabled.

### $t_{\text{pulse}}$ (menu 4.2)

The pulse period can be set between 1...10 s.



*The set pulse period is only effective if the pulser (menu 4.1) is not "inactive".*

The following diagram shows an overview of the pulser control:

### Pulsar control




Fig. 7.1: Pulsar control



## 7.8 Display (menu 5)

Choose whether the measured values for  $R_{NGR}$  and  $I_{NGR}$  should be displayed as absolute (in  $\Omega$  or A) or relative (in % to the reference value). The relative value is the ratio of the measured value to the nominal value.

## 7.9 HRG settings (menu 6)

### 7.9.1 HRG system (menu 6.1)

Menu	Parameter	Setting range	Explanatory notes
6.1.1	$U_{sys}$ (L-L)	400 V...25 kV	System phase-to-phase voltage
6.1.2	CD-NGRM	CD1000, CD5000, CD14400 CD25000 Other	For CD1000 and CD1000-2, select "CD1000" in the menu. The selection depends on the system voltage $U_{sys}$ .
6.1.3	Frequency	50 or 60 Hz	Nominal frequency
6.1.4	$I_{NGR nom}$	0.5...100 A	Nominal value of the NGR current
6.1.5	$R_{NGR nom}$	15...5000 $\Omega$	Nominal value of the used NGR resistance

Tab. 7.2: HRG system (menu 6.1)

### 7.9.2 CT (menu 6.2)

Menu	Parameter	Setting range	Explanatory notes
6.2.1	CT primary	1...10.000	Ratio of the CT on the primary side
6.2.2	CT secondary	1...10.000	Ratio of the CT on the secondary side
6.2.3	CT connection	5 A, 50 mA	Used CT connection

Tab. 7.3: CT (menu 6.2)

### 7.9.3 NGR (menu 6.3)

Menu	Parameter	Setting range	Explanatory notes
6.3.1	Method	auto, passive	<b>auto:</b> automatic changeover between active and passive resistor monitoring; setting for field calibration <b>passive:</b> only passive resistor monitoring (see page 14)
6.3.2	PT primary	1...10.000	Ratio of the potential transformer on the primary side
6.3.3	PT secondary	1...10.000	Ratio of the potential transformer on the secondary side

Tab. 7.4: NGR (menu 6.3)

### 7.9.4 Phase monitor (menu 6.4)

When phase monitoring is used, the faulted phase can be determined in the event of a ground fault.

Menu	Parameter	Setting range	Explanatory notes
6.4.1	Phase monitor	on, off	<b>on:</b> enable function <b>off:</b> disable function (despite wiring, the faulted phase is not signalled)
6.4.2	PT primary	1...10.000	Ratio of the potential transformer on the primary side
6.4.3	PT secondary	1...10.000	Ratio of the potential transformer on the secondary side

Tab. 7.5: Phase monitor (menu 6.4)

### 7.9.5 Response values (menu 6.5)

#### Behaviour of the trip relay in the event of a ground fault

Set whether a ground fault (response value violation  $U_{NGR}$  and/or  $I_{NGR}$ ) should switch the trip relay or not. Set the filter type for NGR current and voltage ("total RMS", "fundamental", or "harmonics") that leads to a violation of the response value at "Trip signal" (menu 6.5.10).

### a) Ground-fault trip (GR trip) (menu 6.5.6) "on"

When a *ground fault* is detected

- the **ground-fault relay** (connections 11, 12, 14) switches **immediately** (40 ms).
- the **trip relay** (connections 31, 32, 34) switches **after  $t_{GF\ trip}$  has elapsed**.

### b) Ground-fault trip (GR trip) (menu 6.5.6) "off"

When a *ground fault* is detected

- the **ground-fault relay** (connections 11, 12, 14) switches **immediately** (40 ms).
- the **trip relay** (connections 31, 32, 34) **does not** switch,  $t_{GF\ trip}$  is ignored.



*When using a coupling device CD14400 or CD25000, the menu item 6.5.6. "off" is not available.*

## Resistor faults

Resistor faults (response value violation  $R_{NGR}$ ) are independent of the "GR trip" settings: The **NGR relay** (connections 21, 22, 24) switches within the response time of approx. 7.5 s. The **trip relay** (connections 31, 32, 34) **switches** with a delay according to the  $t_{NGR\ trip}$  setting.

## Restart of the installation (restart attempts)

Set whether the installation should be restarted manually or automatically after a fault.

### a) Restart installation manually (alarm stored (menu 6.5.8) "on")

In the event of a fault, the trip relay changes state and the installation shuts down. The fault must be eliminated and the installation is restarted via a manual reset (menu 9) or via input I2. If the restart is not successful, it must be re-tried (after further fault elimination).

### b) Restart installation automatically (alarm stored (menu 6.5.8) "off")

In the event of a fault, the trip relay changes state and the installation shuts down. The fault must be eliminated. After the configured time delay  $t_{restart}$  has elapsed, the NGRM700 attempts to restart the installation automatically. If the restart is not successful,  $t_{restart}$  elapses again and another restart attempt takes place. The number of restart attempts can be selected between 1 and 5.



*The NGRM700 remains in "Alarm stored" mode (menu 6.5.8) even after a shutdown.*

## Response values

For delay times, see also page 57.

Menu	Parameter	Setting range	Explanatory notes
6.5.1	$U_{NGR}$ trip	10...90 %	Value in % of the nominal value at which the trip relay and the Ground fault relay operate. <b>Note:</b> The trip relay only operates when ground-fault trip is set to "on" (6.5.6).
6.5.2	$I_{NGR}$ trip	10...90 %	
6.5.3	$> R_{NGR}$	110...200 %	Resistance value in % of the nominal value at which the trip relay and the NGR relay operate.
6.5.4	$< R_{NGR}$	10...90 %	
6.5.5	$t_{NGR}$ trip On the device: $t(NGRtrip)$	0...60 s	Time delay between NGR fault detection and shutdown by the trip relay. $t_{NGR}$ trip is added to the response time.
6.5.6	Ground-fault trip	on	<b>Ground fault:</b> Trip relay switches after the time delay $t_{trip}$ has elapsed. <b>NGR fault:</b> Trip relay switches immediately (< 7.5 s) or after the time delay $t_{NGR}$ trip (0...60 s) has elapsed.
		off <sup>1)</sup>	<b>Ground fault:</b> Trip relay does not switch. <b>NGR fault:</b> Trip relay switches immediately (< 7.5 s) or after the time delay $t_{NGR}$ trip (0...60 s) has elapsed.
6.5.7	$t_{GF}$ trip <sup>2)</sup> On the device: $t(GFtrip)$	100 ms...24 h	Time delay between ground-fault detection and operation of the trip relay; only used when ground-fault trip is set to "on" (6.5.6).
6.5.8	Alarm stored	on	Triggered trip relay must be reset <b>manually</b> (RESET or input I2)
		off	<b>Automatic</b> restart attempts after $t_{restart}$ has elapsed (max. number like setting 6.5.9)
6.5.9	$t_{restart}$ On the device: $t(restart)$	100 ms...24 h	Time delay between fault elimination and automatic restart of the installation; only used when alarm stored (6.5.8) is set to "off".

Menu	Parameter	Setting range	Explanatory notes
6.5.10	Restart count	1...5	Number of restart attempts within 24 h; only used when alarm stored (6.5.8) is set to "off".
6.5.11	Trip signal	RMS	Trips on the full-spectrum RMS value ( $f = DC \dots 3.8 \text{ kHz}$ ).
		Fundamental	Trips on the RMS value of the fundamental.
		Harmonics	Trips on the RMS value within the harmonic upper and lower limits ( 6.5.11 and 6.5.12).
6.5.12	Upper limit harmonic	0...32 0 = DC 1 = fundamental 2 = 2 <sup>nd</sup> Harmonics ...	Indicate range of harmonic that should trigger the trip relay if the threshold value has been exceeded; only active when "Harmonics" is selected at 6.5.10.
6.5.13	Lower limit harmonic	32 = 32 <sup>nd</sup> Harmonics	

*Tab. 7.6: Response values (menu 6.5)*

**Note:**

- 1) When using a coupling device CD14400 or CD25000, the menu item 6.5.6. "off" is not available.
- 2) Observe the maximum trip time (see Tab. 8.1) and the restart time ( $t_{\text{restart}}$ ) for the installed CD-series coupling device when setting the time delay  $t_{\text{trip}}$ .

### 7.9.6 System settings (menu 6.6)

Menu	Parameter		Setting range	Explanatory notes	
6.6.1	Ground-fault relay	Mode (6.6.1.1)	Fail-safe, non-fail-safe	1)	
		Relay test (6.6.1.2)	on, off	2)	
6.6.2	NGR relay	Mode (6.6.2.1)	Fail-safe, non-fail-safe	1)	
		Relay test (6.6.2.2)	on, off	2)	
6.6.3	Trip relay	Mode (6.6.3.1)	Fail-safe, non-fail-safe	1)	
		Relay test (6.6.3.2)	on, off	2)	
6.6.4	Analogue	Mode (6.6.4.1)	0...20 mA 4...20 mA 0...400 $\mu$ A 0... 10 V 2... 10 V	3)	
		Function (6.6.4.2)	$I_{NGR}$ , $R_{NGR}$		
6.6.5	Digital inputs/outputs	Device OUT (6.6.5.1)	Fail-safe, non-fail-safe	1)	
		Pulser OUT (6.6.5.2)	Fail-safe, non-fail-safe		
		Pulser IN (6.6.5.3)	Active high Active low	<b>Active high:</b> Activation of the function when input level changes from "low" to "high" <b>Active low:</b> Activation of the function when input level changes from "high" to "low"	
		RESET IN (6.6.5.4)			
		TEST IN (6.6.5.5)			
6.6.6	Buzzer	Buzzer alarm (6.6.6.1)	on, off		<b>on:</b> each alarm activates buzzer <b>off:</b> alarm does not activate buzzer
		Buzzer test (6.6.6.2)	on, off		<b>on:</b> test activates buzzer <b>off:</b> test does not activate buzzer

Tab. 7.7: System settings (menu 6.6)

### Legend, Tab. 7.7

- 1) Fail-safe: The relay is energised during normal operation and is de-energised in the event of a fault ("fail-safe").  
Non-fail-safe: The relay is de-energised in normal operation and is energised in the event of a fault ("non-fail-safe").
- 2) When set to "on", the function of the relay is checked during a test by switching it.
- 3) Analogue output (menu 6.6.4)  
Either NGR **current**  $I_{\text{NGR}}$  or NGR **resistance**  $R_{\text{NGR}}$  can be assigned to the analogue output. In doing so, the voltage or current is proportional to the measured value. See „chapter 9.1 Analogue output (menu 6.6.4)“ for more details.

### 7.9.7 Field calibration (menu 6.7)

During field calibration, all tolerances of the connected CD-series coupling device and the NGR are considered. The current measured value is calibrated to the set nominal value of the NGR ( $R_{\text{NGR nom}}$ ).

In order to achieve high accuracy, start the device and let it run for at least one hour in the operating environment before carrying out the field calibration.



*For the field calibration the device must run in auto mode (menu 6.3.1 = auto).  
The trip relay is switched during field calibration!*

### 7.10 Device settings (menu 7)

Further information on the configurable parameters can be found following the overview in the table.

Menu	Parameter	Note
7.1	Language	German English GB English US Spanish French

Menu	Parameter	Note	
7.2	Clock	Time (7.2.1)	Set local time
		Format (7.2.2)	12 h (am/pm) 24 h
		Summer time (7.2.3)	Automatic change? <sup>1)</sup>
		Date (7.2.4)	Set date
		Format (7.2.5)	dd.mm.yy mm-dd-yy
		NTP (7.2.6)	Synchronisation on/off <sup>2)</sup>
		NTP server (7.2.7)	IP address NTP server
		UTC (7.2.8)	Time zone <sup>3)</sup>
7.3	Interface <sup>4)</sup>	Write access (7.3.1)	Allow, deny
		Ethernet (7.3.2)	DHCP (7.3.2.1)
			IP (7.3.2.2)
			SN (7.3.2.3)
			Std.GW (7.3.2.4)
			DNS server (7.3.2.5)
			Domain
		BCOM (7.3.3)	System name (7.3.3.1)
			Subsystem (7.3.3.2)
			Device address (7.3.3.3)
			Timeout (7.3.3.4)
			TTL for subscription (7.3.3.5)
		Modbus TCP (7.3.4)	Port 502 (7.3.4.1)
		Modbus RTU (7.3.5)	Address (7.3.5.1)
			Baud rate (7.3.5.2)
			Parity (7.3.5.3)
Stop bits (7.3.5.4)			
7.4	Display <sup>5)</sup>	Brightness (7.4.1)	0...100 %
		Decimal separators (7.4.2)	Comma, point



Menu	Parameter		Note
7.5	Password	Password (7.5.1)	Factory setting 0000
		Status	on, off
7.6	Factory settings		Changes are discarded and reset to factory settings
7.7	Software	Update via interface	6)
		Update	
7.8	Service	For Bender service only	

Tab. 7.8: Device settings overview (menu 7)

### Explanatory notes Tab. 7.8

#### 1) Summer time (menu 7.2.3)

off No automatic change between summer time and standard time.

#### DST Daylight Saving Time

Automatic change between summer time and standard time according to North American regulation. North American summer time begins on each second Sunday in March at 02:00 local time by setting the clock forward by one hour from 02:00 to 03:00 local time. Summer time always ends the first Sunday in October at 03:00 local time by setting the clock back one hour from 03:00 to 02:00.

#### CEST Central European Summer Time

Automatic change between summer time and standard time according to Central European regulation. Central European summer time begins on each last Sunday in March at 02:00 CEST by setting the clock forward by one hour from 02:00 to 03:00. Central European summer time always ends on the last Sunday in October at 03:00 CEST by setting the clock back one hour from 03:00 to 02:00.



*When set to "DST" or "CEST", changing between summer time and normal time is only done on the date of the official time change.*

#### 2) NTP (menu 7.2.6)

on Synchronisation via NTP server is enabled. To use this function, configure the NTP server.

off Synchronisation is disabled.

#### 3) UTC (menu 7.2.8)

Set the time according to UTC (Coordinated Universal Time). For Germany, set +1 for wintertime (MEZ) and +2 for summer time (MESZ).

#### 4) Interface (menu 7.3)

Set the parameters for connecting other communication devices to the NGRM700 in the interface menu:

##### Write access (menu 7.3.1)

Set whether the parameters of the device can be changed via Modbus or web server. Displaying and reading out data via Modbus and web server is always possible, regardless of this setting.

- **Allow** Allow external parameter setting.
- **Deny** Deny external parameter setting.

##### Ethernet (menu 7.3.2)

Set the parameters for communication with other devices via the Ethernet interface. The Ethernet interface can be used for communication with Modbus, web server and BCOM.

##### DHCP (menu 7.3.2.1)

- on** Enable automatic IP address assignment (IP address, subnet mask, standard gateway). Manual address settings are ignored.
- off** Disable automatic IP address assignment. Enter settings (IP address, subnet mask and standard gateway) manually in the menu



*The used IP address is displayed in the Info menu (INFO button or menu 9).*

##### IP (menu 7.3.2.2)

Set the appropriate IP address for the NGRM700.

##### SN (menu 7.3.2.3)

Set the appropriate subnet mask.

##### Std. GW (menu 7.3.2.4)

If a standard gateway is used, enter the IP address here.

##### DNS server (menu 7.3.2.5)

If a DNS server is used, enter the server's IP address. For questions regarding the configuration of a DNS server, please contact your network administrator.

##### Domain (menu 7.3.2.6)

Enter the domain. For questions regarding the configuration of the domain, please contact your network administrator.

### **BCOM (menu 7.3.3)**

Set the parameters for communication with other devices via BCOM. For further information, refer to "BCOM" on page 48.

#### **System name (menu 7.3.3.1)**

Enter the system name of the network in which the devices are located. In order to guarantee that all devices are able to communicate via BCOM, all devices must have the same system name.

#### **Subsystem (menu 7.3.3.2)**

Configure the subsystem address of the network in which the devices are located. The devices can communicate with subsystems with the same or different subsystem addresses.

#### **Device address (menu 7.3.3.3)**

Assign a device address. Each device must have a different address to distinguish it from others in the system and ensure correct communication.

#### **Timeout (menu 7.3.3.4)**

Set the timeout for messages between 100 ms... 10 s. This time specification defines the maximum permissible time for a device to respond.

#### **TTL for subscription (menu 7.3.3.5)**

Set a time between 1 s... 1092 min. This time determines in what intervals the NGRM700 sends messages to e.g. a gateway. Severe alarms are always sent immediately.

### **Modbus TCP (menu 7.3.4)**

Settings for communication with other devices via Modbus TCP.

#### **Port 502 (menu 7.3.4.1)**

Choose whether Modbus TCP should be used:

- on Modbus TCP can be used for communication with other devices.
- off Modbus TCP cannot be used for communication with other devices.

### **Modbus RTU (menu 7.3.5)**

Settings for communication with other devices via Modbus RTU.

Address (menu 7.3.5.1): 1...247

Baud rate (menu 7.3.5.2): the selectable options are

- 9.6 kbaud,
- 19.2 kbaud,
- 38.4 kbaud,
- 57.6 kbaud

Parity: the selectable options are "even", "uneven", "none"

Stop bits: the selectable options are "1", "2", "auto"

#### **5) Brightness (menu 7.5.1)**

Adjust the display brightness between 0...100 % in steps of 10. If no button is pressed on the display for 15 minutes, the brightness of the display decreases. After pressing a button, the display returns to the initial brightness.

## 6) Software (menu 7.7)

### Update via interface (menu 7.7.1)

- off No software update is carried out via the web interface
- on Software updates can be carried out via the web interface

### UPDATE (menu 7.7.2)

If a software package has been transferred to the device, the package can be installed (again) here.

## 7.11 Commissioning (menu 8)

The commissioning wizard queries all relevant parameters.

Language (8.2)	Select
Date (8.3)	Set
Time (8.4)	Set
Usys L-L (8.5)	System voltage
Frequency (8.6)	50 or 60 Hz
INGR nom (8.7)	
RNGR nom (8.8)	
CT primary (8.9)	
CT secondary (8.10)	
CT connection (8.11)	50 mA or 5 A
Field calibration (8.12)	Start or do not start

## 7.12 Info (menu 9)

The NGRM700's current settings can be viewed in the Info menu. Navigate through the different views using the arrow buttons:

Device name, serial number, article number	
Software	Measurement equipment software version, HMI software version
Clock	Time, date, summer time
Ethernet	IP address, DHCP status, MAC address

## 7.13 Alarm (menu 10)

Acknowledge	Mute buzzer, delete message from the standard display, fault message remains stored in the history memory. If the installation is de-energised, no restart attempts will take place.
Reset	Mute buzzer, delete message from the standard display, fault message remains stored in the history memory. If the installation is de-energised, restart attempts will be carried out, which will only be successful after the fault has been eliminated. The device returns to the standard display.
Test	Since the relays are not monitored in the hardware or software, the relays must be tested at regular intervals on proper functioning. The frequency of the test cycle is subject to the safety requirements of the operator but it must be carried out at least every six months.



*During the test it must be ensured that the relays can actually switch! The following settings are required:*

*Ground-fault relay **menu 6.6.1.2** relay test "on"*

*NGR relay **menu 6.6.2.2** relay test "on"*

*Trip relay **menu 6.6.3.2** relay test "on"*

## 8. Initial commissioning

The following parameters must be entered for initial commissioning:

- **System voltage  $U_{sys}$**  (phase-to-phase)  
The corresponding coupling device must be used depending on the system voltage:  
for  $U_{sys} \leq 4.3$  kV: CD1000, CD1000-2, CD5000 (20 k $\Omega$ )  
for  $U_{sys} > 4.3$  kV: CD14400, CD25000 (100 k $\Omega$ )
- **Ratio** of the used **potential transformers** ( $U_{NGR\ nom}$ ) if available
- NGR rated current ( $I_{NGR\ nom}$ )
- **Ratio** of the used **measuring current transformer**  
(600:1 for W... measuring current transformers)
- NGR rated resistance  $R_{NGR\ nom}$



*Parameters are set in the main menu > 6. HRG settings. Alternatively, you can follow the setup wizard (Main menu > 8. Commissioning).*

### 8.1 Response values

The following parameters can be adjusted:

- Trip threshold for voltage ( $U_{NGR}$ )
- Trip threshold for current ( $I_{NGR}$ )
- Trip threshold for resistance ( $R_{NGR}$ )



***Low trip threshold values** may lead to **false tripping**, while with **high trip threshold values** the device may not trip at all.*

#### Voltage trip threshold ( $U_{NGR}$ )

The threshold is set as a percentage of  $U_{NGR\ nom}$ .

Setting range of trip threshold  $U_{NGR}$ : 10...90 % (factory setting 60 %)

#### Current trip threshold ( $I_{NGR}$ )

The trip threshold is set as a percentage of  $I_{NGR\ nom}$ .

Setting range of trip threshold  $I_{NGR}$ : 10...90 % (factory setting 60 %).

### Resistance trip threshold ( $R_{NGR}$ )

Both trip thresholds for the resistance are set as a percentage of the nominal NGR.

Setting range of trip threshold  $R_{NGR}$

10...90 % (factory setting 50 %)

110...200 % (factory setting 200 %).

In the case of the **passive measurement method** the resistance  $R_{NGR}$  is determined using the current and voltage measurements. Accuracy depends on the measuring current transformer.

In the case of the **active measurement method** the device generates an active test pulse and measures  $R_{NGR}$  even if the installation is de-energised.

## 8.2 Output relays operating modes

The factory setting for the relays is fail-safe. In the case of a device test, the relays change state. The settings can be changed in *menu 6.6.1...6.6.6* (see page 46).

### 8.2.1 Field calibration

After the parameters have been entered, a field calibration must be carried out. During this process, the set resistance value of the NGR calibrates to the measurement equipment of the NGRM. For the field calibration the device must run in auto mode (menu 6.3.1 = auto).



*Start field calibration in the  
**main menu > 6.7 Field calibration.***

If calibration is not possible (e.g. due to incorrect settings) an error message appears (6.10).

### 8.2.2 Trip times

The three relays have different trip times:

- Ground-fault relay      40 ms, not configurable
- NGR relay                    7.5 s, not configurable
- Trip relay                    100 ms...24 h, configurable for ground faults  
                                     0...60 s, configurable for NGR faults

### Explanatory notes on trip relay

1. In case of a ground fault,  $t_{GF \text{ trip}}$  is only considered when "GR trip" (menu 6.5.6) is enabled. When "GR trip" is disabled, the trip relay does not switch in the event of a ground fault.
2. In case of an NGR fault,  $t_{GF \text{ trip}}$  is ignored, the trip relay switches after time delay  $t_{NGR \text{ trip}}$  has elapsed.
3. The setting for  $t_{GF \text{ trip}}$  must under no circumstances be longer than the maximum possible operating time of the CD-NGRM... coupling device.

The table shows an overview of the  $t(GFtrip)$  settings for the coupling device used :

$U_{sys}$	Coupling device	Max. $t_{trip}$ (Menu 6.5.7)	Ground-fault trip settings (menu 6.5.6)
400...690 V	CD1000	24 h	on or off
	CD1000-2		
691...1000 V	CD1000	300 s	on
	CD1000-2	24 h	on or off
	CD5000		
1001...4300 V	CD5000	24 h	on or off
4301...14550 V	CD14400	60 s	on
	CD25000		
14551...25000 V	CD25000	10 s	on

Tab. 8.1: Maximum trip times  $t(GFtrip)$  for the used CD-NGRM



### Ground-fault relay timing diagram




Fig. 8.1: Ground-fault relay timing diagram

### NGR relay timing diagram




Fig. 8.2: NGR relay timing diagram

### 8.3 RMS trip signal, fundamental, harmonics

Which measured value causes tripping can be selected via the "Trip signal" parameter (menu 6.5.10). Trip signal can be:

#### RMS

The RMS value of current or voltage over the entire frequency range (up to approx. 3.8 kHz).

#### Fundamental

Only the RMS value of the fundamental component (50 or 60 Hz).

#### Harmonics

The filtered RMS value on the selected range of harmonics

H0 = DC

H1 = fundamental

H2 = 2<sup>nd</sup> Harmonics

...

H32 = 32<sup>nd</sup> Harmonics



*In the "Harmonics" measured value display (menu 2) all spectral lines are always displayed. This is independent of the trip signal setting.*



*On the standard display, the trip signal is indicated as*

- *resistance in  $\Omega$  or %*
- *current in A or %*

*. Setting is entered in the main menu > 5: Display.*

### 8.4 Initial measurement

During device start, all measured values are recorded.

### Device start timing diagram




Fig. 8.3: Device start timing diagram

## 9. Analogue and digital I/O configuration

### 9.1 Analogue output (menu 6.6.4)

Either NGR **current**  $I_{NGR}$  or NGR **resistance**  $R_{NGR}$  can be assigned to the analogue output. A voltage or current signal proportional to the measured value is applied to the output. The following settings are possible:

#### Mode (menu 6.6.4.1)

- 0...20 mA                      Permissible load  $\leq 600 \Omega$
- 4...20 mA                      Permissible load  $\leq 600 \Omega$
- 0...400  $\mu$ A                      Permissible load  $\leq 4 \text{ k}\Omega$
- 0...10 V                          Permissible load  $\geq 1 \text{ k}\Omega$
- 2...10 V                          Permissible load  $\geq 1 \text{ k}\Omega$

For further information, refer to „X1: Analogue output“ on page 31.

#### Function (menu 6.6.4.2)

Set which measured values are assigned to the analogue output. Setting options:

- $I_{NGR}$
- $R_{NGR}$

### 9.2 Digital outputs (Q1, Q2)

The digital outputs can draw current (sink).

The current for the Open-Collector output is 300 mA for each output.

Since the "+24 V" connection can only provide 100 mA, it might be required to use an external voltage supply (+24 V) for the relays.



*Modes:*

- *Fail-safe mode*

- *Non-fail-safe mode*

### 9.2.1 Use of Q1: Device condition

Mode	No device error detected	Device error detected <sup>1)</sup>
<b>Fail-safe</b>	on energised Q1 low	off de-energised Q1 high
<b>Non-fail-safe</b>	off de-energised Q1 high	on energised Q1 low

Intern. 24 V

**X1**

<sup>1)</sup> The SERVICE LED is also on

### 9.2.2 Use of Q2: Pulsar

Mode	Inactive	Active
<b>Fail-safe</b>	on energised Q2 low	off de-energised Q2 high
<b>Non-fail-safe</b>	off de-energised Q2 high	on energised Q2 low

Intern. 24 V

**X1**

## 9.3 Digital input

The input is only detected as "activated" after the contact has been **activated for at least 150 ms**. This way, short interference pulses are ignored.

For further information, refer to page 29.

## 10. Test cycle

Since the relays are not monitored in the hardware or software, the relays must be tested at regular intervals to verify proper functioning. The frequency of the test cycle is subject to the safety requirements of the operator but it must be carried out at least every six months.



*During the test it must be ensured that the relays can actually switch off!*

*The following settings are required:*

*Ground-fault relay*    **menu 6.6.1.2** relay test "on"

*NGR relay*            **menu 6.6.2.2** relay test "on"

*Trip relay*            **menu 6.6.3.2** relay test "on"

### Starting the test

Start the test whether directly by pressing the TEST button or via the menu 10.3 or the input I3 (activate for more than 150 ms).

# 11. Factory settings

Menu	Factory settings
<b>Menu 6.1: HRG system</b>	
1. $U_{\text{sys}}$ (L-L)	400 V
2. CD-NGRM	CD1000
3. Frequency	50 Hz
4. $I_{\text{NGR nom}}$	5 A
5. $R_{\text{NGR nom}}$	470 $\Omega$
<b>Menu 6.2: CT</b>	
1. CT primary	600
2. CT secondary	1
3. CT connection	50 mA
<b>Menu 6.3: NGR</b>	
1. Method	auto
2. PT primary	1
3. PT secondary	1
<b>Menu 6.4: Phase monitor</b>	
1. Phase monitor	on
2. PT primary	1
3. PT secondary	1
<b>Menu 6.5: Response values</b>	
1. $U_{\text{NGR trip}}$	60 %
2. $I_{\text{NGR trip}}$	60 %
3. $> R_{\text{NGR}}$	150 %
4. $< R_{\text{NGR}}$	50 %
5. $t_{\text{NGR trip}}$	0 s
6. Ground-fault trip	yes

Menu	Factory settings
7. $t_{GF}$ trip	5 s
8. Alarm stored	on
9. $t_{restart}$	5 s
10. Restart count	2
11. Trip signal	RMS
12. Upper limit harmonic	32
13. Lower limit harmonic	0
<b>Menu 6.6: System settings</b>	
1. Ground-fault relay	Mode fail-safe Rel. test on
2. NGR relay	Mode fail-safe Rel. test on
3. Trip relay	Mode fail-safe Rel. test on
4. Analogue	Mode 4-20 mA Function R NGR
5. Dig. in/out	Device OUT fail-safe Pulser OUT non-fail-safe Pulser IN active high RESET IN active high TEST IN active high
6. Buzzer	Buzzer alarm off Buzzer test on



## 12. Error codes

Error code/ Service code	Description/Cause	Action
6.10	Error during field calibration	Restart field calibration. If the error persists, contact service.
6.11	Field calibration could not be started	The installation must operate error-free before starting a field calibration. Restart field calibration. If the error persists, contact service.
7.61...7.63	Connection between measuring equipment and display unit interrupted or disturbed.	Check connection between measuring equipment and display unit. Restart device.
8.03 and 8.12	Error in the measuring signal generation	Restart device. If the error persists, contact service.
8.43	Error in the internal power supply unit ( <i>positive supply voltage</i> )	Restart device. If the error persists, contact service.
8.44	Error in the internal power supply unit ( <i>negative supply voltage</i> )	Restart device. If the error persists, contact service.
8.46	Error in the internal power supply unit ( <i>supply voltage</i> )	Restart device. If the error persists, contact service.
8.48	Error in the internal power supply unit ( <i>reference voltage</i> )	Restart device. If the error persists, contact service.
All other error codes		Contact service.

## 13. Technical data

### 13.1 Tabular data

#### Insulation coordination according to IEC 60664-1/IEC 60664-3/DIN EN 50178

##### Definitions

Measuring circuit 1 (IC1) .....	(L1, L2, L3)
Supply circuit (IC2) .....	(A1, A2)
Measuring circuit/Control circuit (IC3) .....	(RS, E, CT), (X1, Ethernet)
Output circuit 1 (IC4) .....	(11, 12, 14)
Output circuit 2 (IC5) .....	(21, 22, 24)
Output circuit 3 (IC6) .....	(31, 32, 34)
Rated voltage .....	690 V
Overvoltage category .....	III

##### Rated impulse voltage

IC1 / (IC2 . . . 6) .....	8 kV
IC2 / (IC3 . . . 6) .....	4 kV
IC3 / (IC4 . . . 6) .....	4 kV
IC4 / (IC5 . . . 6) .....	4 kV
IC5 / (IC6) .....	4 kV

##### Rated insulation voltage

IC1 / (IC2 . . . 6) .....	800 V
IC2 / (IC3 . . . 6) .....	250 V
IC3 / (IC4 . . . 6) .....	250 V
IC4 / (IC5 . . . 6) .....	250 V
IC5 / (IC6) .....	250 V
Pollution degree exterior .....	3

##### Safe isolation (reinforced insulation) between

IC1 / (IC2 . . . 6) .....	overvoltage category III, 800 V
IC2 / (IC3 . . . 6) .....	overvoltage category III, 300 V
IC3 / (IC4 . . . 6) .....	overvoltage category III, 300 V
IC4 / (IC5 . . . 6) .....	overvoltage category III, 300 V
IC5 / (IC6) .....	overvoltage category III, 300 V

**Voltage tests (routine test) acc. to IEC 61010-1**

IC2 / (IC3 . . 6) .....	AC 2.2 kV
IC3 / (IC4 . . 6) .....	AC 2.2 kV
IC4 / (IC5 . . 6) .....	AC 2.2 kV
IC5 / (IC6) .....	AC 2.2 kV

**Supply voltage**

Nominal supply voltage $U_s$	
$\leq 2000$ m .....	AC/DC, 24 . . 240 V
$\leq 2000$ m (for UL applications) .....	AC/DC, 48 . . 240 V
$\leq 2000$ m (for AS/NZS 2081 applications) .....	AC/DC, 48 . . 230 V
$> 2000$ . . $\leq 5000$ m .....	AC/DC, 24 . . 120 V
$> 2000$ . . $\leq 5000$ m (for UL and AS/NZS 2081 applications) .....	AC/DC, 48 . . 120 V
Tolerance $U_s$ .....	$\pm 15$ %
Tolerance $U_s$ (for UL applications) .....	$-50$ . . $+15$ %
Tolerance $U_s$ (for AS/NZS 2081 applications) .....	$-25$ . . $+20$ %
Frequency range $U_s$ .....	DC, 40 . . 70 Hz
Power consumption (typ. 50/60 Hz) .....	$\leq 6.5$ W / 13 VA

**Phase monitoring**

Nominal measuring voltage $U_n$ .....	3 AC 100 . . 690 V, CAT III
Measuring range .....	$1.2 \times U_n$
Measurement accuracy .....	$\pm 1$ % of $U_n$
Power consumption per phase .....	$\leq 0.5$ W
Overload capacity .....	$2 \times U_n$ continuous
Input resistance .....	$1.76$ M $\Omega$
PT ratio primary .....	1 . . 10,000
PT ratio secondary .....	1 . . 10,000
Measuring range with PT .....	100 V . . 25 kV

### Monitoring $R_{NGR}$

Measuring input $R_S$ .....	< 33 V RMS
Measuring range NGR (with $R_S = 20\text{ k}\Omega$ ) active.....	0... 10 k $\Omega$
Measurement uncertainty for $T = 0... +40\text{ }^\circ\text{C}$ .....	$\pm 20\text{ }\Omega$
Measurement uncertainty for $T = -40... +70\text{ }^\circ\text{C}$ .....	$\pm 40\text{ }\Omega$
Measuring range NGR (with $R_S = 100\text{ k}\Omega$ ) active.....	0... 10 k $\Omega$
Measurement uncertainty for $T = 0... +40\text{ }^\circ\text{C}$ .....	$\pm 30\text{ }\Omega$
Measurement uncertainty for $T = -40... +70\text{ }^\circ\text{C}$ .....	$\pm 80\text{ }\Omega$
Setting range $R_{NGR\text{ nom}}$ .....	15 $\Omega$ ... 5 k $\Omega$
Response value $R_{NGR\text{ nom}}$ .....	10... 90 % $R_{NGR\text{ nom}}$
.....	110... 200 % $R_{NGR\text{ nom}}$
Response delay NGR relay.....	7 s ( $\pm 2.5$ s)
Response delay trip relay.....	0... 60 s

### Monitoring $I_{NGR}$

Measuring circuit 5 A	
Nominal measuring current $I_n$ .....	DC / 50/60 Hz / 50... 3200 Hz 5 A
Maximum continuous current.....	$2 \times I_n$
Overload capacity.....	$10 \times I_n$ for 0.03 s
Measurement accuracy.....	$\pm 2\%$ of $I_n$
Load.....	10 m $\Omega$
Measuring circuit 50 mA	
Nominal measuring current $I_n$ .....	DC / 50/60 Hz / 50... 3200 Hz 50 mA
Maximum continuous current.....	$2 \times I_n$
Overload capacity.....	$10 \times I_n$ for 2 s
Measurement accuracy.....	$\pm 2\%$ of $I_n$
Load.....	68 $\Omega$
Measuring circuits 5 A and 50 mA	
Response value $I_{NGR}$ .....	10... 90 % $I_{NGR\text{ nom}}$
Response delay ground-fault relay.....	$\leq 40\text{ ms}$ ( $\pm 10\text{ ms}$ )
Response delay trip relay (configurable).....	100 ms... 24 h, $\infty$
Tolerance $t_{\text{trip}}$ when set to	
RMS.....	-20... 0 ms
Fundamental.....	0... +150 ms (filter time)
Harmonics.....	0... +150 ms (filter time)
Measuring current transformer ratio primary.....	1... 10,000
Measuring current transformer ratio secondary.....	1... 10,000
Measuring range.....	$2 \times I_{NGR\text{ nom}}$

**Coupling**

$R_S$ for $U_{sys} \leq 4.3$ kV.....	CD1000, CD1000-2, CD5000 (20 k $\Omega$ )
$R_S$ for $U_{sys} > 4.3$ kV.....	CD14400, CD25000 (100 k $\Omega$ )

**Monitoring  $U_{NGR}$**

$U_{NGR}$ with $R_S = 20$ k $\Omega$ .....	DC / 50/60 Hz / 50...3200 Hz; (400/ $\sqrt{3}$ ) ... $\leq (4300/\sqrt{3})$ V
$U_{NGR}$ with $R_S = 100$ k $\Omega$ .....	DC / 50/60 Hz / 50...3200 Hz; $> (4.3 / \sqrt{3})$ ... (25/ $\sqrt{3}$ ) kV
Measuring range.....	1.2 x $U_{NGR}$ nom
Overload capacity.....	2 x $U_{NGR}$ for 10 s
Measurement accuracy.....	2 % of $U_{NGR}$ nom with $U_{NGR}$ nom = ( $U_{sys(L-L)}/\sqrt{3}$ )
Voltage response value.....	10...90 % $U_{NGR}$ nom
Response delay ground-fault relay.....	$\leq 40$ ms ( $\pm 10$ ms)
Response delay trip relay (configurable).....	100 ms...24 h, $\infty$
Tolerance $t_{trip}$ when set to	
RMS.....	-20...0 ms
Fundamental.....	0...+150 ms (filter time)
Harmonics.....	0...+150 ms (filter time)
PT ratio primary.....	1...10,000
PT ratio secondary.....	1...10,000
DC immunity in case of active $R_{NGR}$ measurement	
with $R_S = 20$ k $\Omega$ .....	DC $\pm 12$ V
with $R_S = 100$ k $\Omega$ .....	DC $\pm 60$ V

**Digital inputs**

Galvanic separation.....	no
Length connecting cables.....	max. 10 m
$U_{in}$ .....	DC 0 V, 24 V
Overload capacity.....	-5...32 V

**Digital outputs**

Galvanic separation.....	no
Length connecting cables.....	max. 10 m
Currents (sink) for each output.....	max. 300 mA
Voltage.....	24 V
Overload capacity.....	-5...32 V

### Analogue output (M+)

Operating mode.....	Linear
Functions.....	$I_{NGR}, R_{NGR}$
Current.....	0...20 mA ( $\leq 600 \Omega$ ), 4...20 mA ( $\leq 600 \Omega$ ), 0...400 $\mu$ A ( $\leq 4 \text{ k}\Omega$ )
Voltage.....	0...10 V ( $\geq 1 \text{ k}\Omega$ ), 2...10 V ( $\geq 1 \text{ k}\Omega$ )
Tolerance related to the current/voltage end value.....	$\pm 20 \%$

### Ground-fault, NGR, trip relay

Switching elements.....	changeover contacts
Operating mode.....	configurable fail-safe/non-fail-safe
Electrical endurance, number of cycles.....	10,000
Switching capacity.....	2000 VA / 150 W
Contact data acc. to IEC 60947-5-1	
Rated operational voltage AC.....	250 V/250 V
Utilisation category.....	AC-13/AC-14
Rated operational current AC.....	5 A/3 A
Rated operational current AC (for UL applications).....	3 A/3 A
Rated operational voltage DC.....	220/110/24 V
Utilisation category.....	DC12
Rated operational current DC.....	0.1/0.2/1 A
Minimum current.....	1 mA at AC/DC > 10 V

### Environment/EMC

EMC immunity (IEC 61000-6-2 / IEC 60255-26 Ed. 3.0).....	DIN EN 61000-6-2
EMC emission (IEC 61000-6-4 / IEC 60255-26 Ed. 3.0).....	DIN EN 61000-6-4
Operating temperature.....	-40...+70 °C
.....	-40...+60 °C (for UL applications)
Humidity.....	$\leq 98 \%$
Classification of climatic conditions acc. to IEC 60721 (except condensation and formation of ice)	
Stationary use (IEC 60721-3-3).....	3K23
Transport (IEC 60721-3-2).....	2K11 (-40...+85 °C)
Long-term storage (IEC 60721-3-1).....	1K22 (-40...+70 °C)
Classification of mechanical conditions acc. to IEC 60721 / IEC 60255-21 / DIN EN 60068-2-6	
Stationary use.....	3M12
Transport.....	2M4
Long-term storage.....	1M12

**Connection**

Screw-type terminals

Tightening torque .....	0.5 . . . 0.6 Nm (5 . . . 7 lb-in)
Conductor sizes .....	AWG 24-12
Stripping length .....	7 mm
rigid/flexible.....	0.2 . . . 2.5 mm <sup>2</sup>
flexible with ferrule with/without plastic sleeve.....	0.25 . . . 2.5 mm <sup>2</sup>
Multiple conductor, rigid.....	0.2 . . . 1 mm <sup>2</sup>
Multiple conductor flexible .....	0.2 . . . 1.5 mm <sup>2</sup>
Multiple conductor flexible with ferrule without plastic sleeve .....	0.25 . . . 1 mm <sup>2</sup>
Multiple conductor, flexible with TWIN ferrule with plastic sleeve.....	0.5 . . . 1.5 mm <sup>2</sup>

Push-wire terminals X1

Conductor sizes .....	AWG 24-16
Stripping length .....	10 mm
rigid/flexible.....	0.2 . . . 1.5 mm <sup>2</sup>
flexible with ferrule without plastic sleeve .....	0.25 . . . 1.5 mm <sup>2</sup>
flexible with ferrule with plastic sleeve.....	0.25 . . . 0.75 mm <sup>2</sup>

**Other**

Operating mode .....	continuous operation
Mounting .....	display-oriented
Altitude.....	5000 m AMSL
Degree of protection, internal components (DIN EN 60529) .....	IP30
Flammability class .....	UL 94V-0
Protective coating measurement equipment.....	SL1307, UL file E80315
Weight.....	1050 g

**Standards, approvals, certifications**

The specified standards take into account the edition valid until 04.2021 unless otherwise indicated.



UL file number: E493737, E173157

## 13.2 Ordering details

### 13.2.1 NGR monitor

Type	Supply voltage/Frequency range $U_S$	Art. No.
NGRM700	AC 24...240 V, 40...70 Hz DC 24...240 V	B94013700
Accessory for FP200-NGRM: Transparent front cover 144x72 (for IP65)*		B98060005

\*When using the "transparent front cover 144x72 (IP 65)" the cutout in the switchboard cabinet must be extended in height from 66 mm to 68 mm (+0.7/-0 mm). The degree of protection IP65 applies only to the user interface FP200-NGRM when using the front cover. The degree of protection for the complete device is still IP30.

### 13.2.2 Accessories

#### CD-series coupling device

Voltage $U_{sys}$	Type	Art. No.
400...690 V	CD1000	B98039010
400...1000 V	CD1000-2	B98039053
1000...4200 V	CD5000	B98039011
4300...14550 V	CD14400	B98039054
14551...25000 V	CD25000	B98039055



### Measuring current transformer

Voltage/Current	Type	Art. No.
AC up to 10 A	W20	B98080003
AC up to 25 A	W35	B98080010
	W60	B98080018
	W0-S20	B911787
	W1-S35	B911731
	W2-S70	B911732
AC/DC up to 10 A	CTUB103-CTBC35	B78120030
AC/DC up to 25 A	CTUB103-CTBC60	B78120031
	CTUB103-CTBC120	B78120032

### Voltage supply for

Measuring current transformers CTUB103...

Max. connected measuring current transformers	Type	Art. No.
2	STEP-PS/1 AC/24 DC/0.5	B94053110
7	STEP-PS/1 AC/24 DC/1.75	B94053111
17	STEP-PS/1 AC/24 DC/4.2	B94053112

### 13.3 Document revision history

Datw	Document version	State/Changes
04.2021	06	<i>Editorial revision</i> Distinction between "system" and "device" <i>Deleted</i> Measuring current transformer W...AB (discontinued)







# INDEX

## A

Acknowledging a fault message 35  
Alarm 53  
Analogue output 60

## B

BCOM 51

## C

CEST (Central European Summer Time) 49  
Connection  
    - Measuring current transformer 27  
    - relay 28  
    - Usys > 690 V 25  
    - Usys ≤ 690 V 23  
    - Usys ≤ 690 V with pulser 24  
    - with a zigzag transformer 26  
    - X1 interface 28  
Coupling device 14  
CT 41

## D

Data measured values 38  
Delta connection 26  
Device address 51  
Device buttons 33  
Device features 13  
Device settings 47  
DHCP 50  
Digital input 61  
Digital output 60  
Display 41  
Display and operating controls 32  
Disposal 10  
DNS server 50  
Domain 50  
Door mounting FP200-NGRM 20  
DST (Daylight Saving Time) 49

## E

Enclosure view 19  
Error codes 65  
Ethernet 50

## F

Factory settings 63  
Fault indication 34, 35  
Field calibration 47, 55  
FP200-NGRM 19, 20, 32

## G

Glossary 12  
Ground fault 14

## H

Harmonics 39  
History 40  
History memory 36  
How to use this manual 7  
HRG settings 41

## I

Info 52  
Initial commissioning 54  
Initial measurement 58  
Intended use 11  
Interface 50  
IP 50

## M

Measurement method  
    - passive 14, 55  
Menu 37  
Menu 1 38  
Menu 2 39  
Menu 3 40

Menu 4 40  
Menu 5 41  
Menu 6 41  
Menu 7 47  
Menu 8 52  
Menu 9 53  
Modbus TCP 51

## N

NTP 49

## O

Ordering details 72

## P

Password 52  
Phase monitor 14, 42  
Pulser 40

## Q

Q1 (Pulser) 61  
Q2 (system health) 61

## R

Removing FP200-NGRM 19  
Resistor monitoring 14  
Response values 42, 54

## S

Service 8  
Settings 38  
SN (subnet mask) 50  
Software update 52  
Standard display 34  
Standard gateway 50  
Star connection  
- U<sub>sys</sub> > 690 V 25

- U<sub>sys</sub> ≤ 690 V 23

Subsystem 51

Support 8

## T

Technical data 66

Test cycle 62

Timing diagram

- Ground-fault relay 57

- NGR relay 57

Training courses 9

Trip signal 58

Trip threshold

- current 54

- resistance 55

- voltage 54

Trip times 55

TTL for subscription 51

## U

User interface FP200-NGRM 32

## W

Work activities on electrical installations 11

Workshops 9

Write access 50

## X

X1

- Analogue output 31

- Input I1...3 29

- Output Q1...2 30





## **Bender GmbH & Co. KG**

Londorfer Straße 65 • 35305 Grünberg • Germany  
Tel.: +49 6401 807-0 • [info@bender.de](mailto:info@bender.de) • [www.bender.de](http://www.bender.de)

## **USA**

Exton PA, USA  
800.356.4266 / 610.383.9200 • [info@bender.org](mailto:info@bender.org)  
[www.bender.org](http://www.bender.org)

## **Canada**

Mississauga ON, Canada  
800.243.2438 / 905.602.9990 • [info@bender-ca.com](mailto:info@bender-ca.com)  
[www.bender-ca.com](http://www.bender-ca.com)

## **Mexico, South America, Central America, Caribbean**

[info@bender-latinamerica.com](mailto:info@bender-latinamerica.com)  
[www.bender-latinamerica.com](http://www.bender-latinamerica.com)

All rights reserved.  
Reprinting and duplicating  
only with permission of the publisher.  
Subject to change!

Photos: Bender Archive



**BENDER Group**